

Rytool RT0160 - Noid Light Set



Product Description

- Save Time Save Money. The most economical way to check electronic fuel injection (EFI) signals.
- ullet Quickly & easily checks for systems of GM PEI, FORD TBI, GEO TBI, BOSCH PFI, GM TBI & GM SCPI.
- Simply disconnect the fuel injectors, plug the Noid Lite into injector wiring harness, then crank the engine.