

Cabac MONKEY - Blue Monkey Level Stencil



Product Description

Features

- A clever self-leveling stencil to assist with fitting C-brackets for plug points and light switches
- Fast, clean and accurate installations every time
- Easy to position and mark C-bracket cut-out
- Vertical and horizontal level indication

Instructions

1. Measure the position desired for the plug point and mark the centre point of the hole you wish to cut for a C-bracket.
2. Check for studs, metal brackets and power cords behind the plaster board using a suitable stud finder.
3. If there are no studs, place the Blue Monkey™ and match the cross-hair in the centre with the marked point on the plaster board.
4. Check that the Blue Monkey™ is level (horizontally or vertically) and draw around the stencil with a pencil or pen.
5. Using a Wall Board Saw, cut around the outline.
6. Place a C-bracket in the cut-out hole.
7. Connect and fit the plug point.